



EN Tip for Extra Stability



EN For extra stability of your umbrella against the wind, use the pegs and cords included in the carry bag.



Hang the spring clip of the cord on the hanging loop located at the edge of the canopy ribs.



Adjust the cord length using the runner. Tense the cord by anchoring it to the ground with the peg.



Your umbrella is now stable against the wind. Enjoy your shade!

RUAKIRI PLUS 
TERRANATION

